

## QUICK START GUIDE

The button on the back turns on power, the display appears:

```

1 2 0  V 5 S 1
4 t r  M 4
    
```

See the cursor, (presently on meter). The cursor indicates what can be adjusted using the + - (plus minus) buttons. The action must be stopped to change meter, all others can be adjusted "on the fly".

Stop/start button **||▶** upper right starts action.

Starting action with the **||▶** button moves the cursor to volume. Use + - buttons to change volume.

Use the select button. **↑** to move cursor to sound and subdivision, then use the + - buttons to change sound and subdivision.

Stopping action with the **||▶** button moves cursor to meter. Use + - buttons to select any of 7 meters and 6 polymeters.

The tempo button **⌚** moves cursor to tempo. + - buttons moves tempo up and down.

Press any beat to bring up the individual beat display:

```

V 5 S 1
4 t r
    
```

Use the select **↑** buttons and + - buttons to change that beat. You can change the volume, sound, or subdivision of selected beat.

Press the tools button **⚙️** to bring up subdivision display:

```

SubDiV
V 5 S 1
    
```


Use the **↑** button and + - buttons to change subdivision v or s.

Tool button also brings up tap function and pitch function.

Use tempo button **⌚** to tap in tempo, + - button to change pitch.

Press the memory button **🧠** to bring up memory function.

Use the select **↑** buttons and + - buttons for memory options.



### Displays

#### Global

```

1 2 0  V 5 S 1
4 t r  M 4
    
```

#### beat

```

V 5 S 1
4 t r
    
```

#### subdivision

```

SubDiV
V 5 S 1
    
```

Upper left number = tempo

V = volume

S = sound

Lower left figure = subdivision

(4tr, 8th, trp, 16th, 5s 6s 7s 32nd etc see manual)

M = meter

For more information please consult the manual